

Engine Stop Leak

Nulon Engine Stop Leak reduces annoying oil leaks in all petrol, diesel and LPG engines. Use this product if your car has any of the following symptoms: loses or leaks oil, blows blue smoke at start-up, on take-off after a period of idling at traffic lights, or when decelerating downhill.

NOTE: Can be used to control leaks in manual gearboxes and differentials.

Benefits

- Reduces oil leaks
- Rejuvenates hardened or shrunken seals
- Reduces exhaust smoke at start-up or on take-off
- Reduces oil consumption & oil burning
- Can save the expense of seal replacement
- Reduces leaks in all types of gearboxes & differentials



Directions for use

Add 1 bottle for every 5 litres of engine oil. Shake bottle and add contents to engine oil. Idle engine for at least 1 minute. Use with every oil change. To reduce gearbox and diff oil leaks, add 60 ml per litre of oil.

NOTE: It may take 14 days or 500 km to achieve maximum benefits. Excessively worn or damaged seals may not respond and will require replacement.

First Aid

For advice, contact a Poisons Information Centre (Phone e.g. Australia 131 126; New Zealand 0800 764 766) or a doctor (at once).

Pack Sizes



Part No: ESL

300 ml - 6 Per Carton

Barcode: 931109000384